Problem 1.

Use the NIST ASTAR to find the range of a $10\,\mathrm{MeV}$ alpha particle, and then use the range values at lower energies to determine at what depth a $10\,\mathrm{MeV/nucleon}$ alpha particle has traveled 99% of its range. Do the same for a $20\,\mathrm{MeV/nucleon}$ alpha and $50\,\mathrm{MeV/nucleon}$ alpha. Use this information for your semester stopping power assignment to help guide you in determining a lower energy limit/cutoff when calculating ranges.

Solution

Problem 2. Anderson 4.2

Use Eqution 4.13 to calculate the range of a 5 MeV alpha particle in N₂ gas at 760 mmHg pressure. Assume that the exponential integral at T_1 (low-energy limit) and $R_1(T_1)$ can be neglected.

$$R = \frac{Mc^{2}I^{2}}{32z^{2}\pi r_{0}^{2} (m_{e}c^{2})^{3} N_{A} (Z/M_{m}) \rho} \int_{u_{1}}^{u_{0}} \frac{du}{\ln u} + R_{1} (T_{1})$$

$$= \frac{Mc^{2}I^{2}}{32z^{2}\pi r_{0}^{2} (m_{e}c^{2})^{3} N_{A} (Z/M_{m}) \rho} \left[\text{Ei} (\ln u_{0}) - \text{Ei} (\ln u_{1}) \right] + R_{1} (T_{1})$$
(4.13)

Solution

Problem 3. Anderson 4.5

Calculate the ratio of the range of a $14\,\mathrm{MeV}$ $^{14}\mathrm{N}^{+++}$ ion to the range of a $1\,\mathrm{MeV}$ proton. Use equation 4.18.

$$(R\rho)_b \approx \frac{(M/z^2)_b}{(M/z^2)_a} (R\rho)_a \tag{4.18}$$

Solution

We know that for particles with similar values of $\tau = T/mc^2$, equation 4.18 can be used to compare Range-density values. Therefore:

$$\begin{split} (R\rho)_b &\approx \frac{(M/z^2)_b}{(M/z^2)_a} \left(R\rho\right)_a \\ &\approx \frac{\left(14/3^2\right)_b}{\left(1/1^2\right)_a} \left(R\rho\right)_a \\ &\approx 1.56 \left(R\rho\right)_a \end{split}$$

The $14\,\mathrm{MeV}^{-14}\mathrm{N}^{+++}$ ion will travel approximately 1.56 times further than the $1\,\mathrm{MeV}$ proton.

Problem 4.

Use the NIST PSTAR utility to do the following: produce a Bragg Curve for 250 MeV protons passing through a variable water column, as measured by two air ionization chambers, each 1 cm thick. Neglect energy loss in the ion chamber windows and in any air gaps between the ion chambers and water column. NIST states a 250 MeV proton ranges out in about 38 cm of water, so calculate the ratio of the ion chamber currents at 0 cm, 10 cm, 20 cm, 30 cm, 35 cm, 36 cm, 37 cm and 38 cm of water between the ion chambers.

Assume dry air in the ion chambers at a density of $0.0012\,\mathrm{g/cm^3}$. More details about this problem will be covered in class.

Solution